




# BoosterpaQ Hydro MPC-ES



- The MPC-ES system maintains a constant pressure through continuous adjustment of the speed of the CRE pump. The other pumps are cut in/out according to demand to achieve a performance corresponding to the consumption.

- The CRE pump always starts first. If the pressure cannot be maintained by the pump, one or both CR pumps will be cut in.

- Changeover among the constant speed pumps is automatic and depends on load, operating hours and fault.