




BoosterpaQ Hydro MPC-F



- The MPC-F system maintains a constant pressure through continuous adjustment of the speed of the CR pump connected to the external variable frequency drive.

- The speed-controlled operation alternates between the pumps.

- One CR pump connected to the external variable frequency drive always starts first. If the pressure cannot be maintained by the pump, one or two constant speed CR pumps will be cut in.

- Pump changeover is automatic and depends on load, operating hours and fault.